


Task Title:  
CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3



## Task Title: Calculating Linear Pipe Expansion

OALCF Cover Sheet – Practitioner Copy

**Learner Name:** \_\_\_\_\_

**Date Started:** \_\_\_\_\_

**Date Completed:** \_\_\_\_\_

**Successful Completion:** Yes  No

**Goal Path:** Employment  Apprenticeship

Secondary School  Post Secondary  Independence

**Task Description:** Understand and calculate linear pipe expansion when installing plumbing pipes.

\* Tasks 1 and 2 are complex and may require some prior knowledge of the trade to complete.

### Main Competency/Task Group/Level Indicator:

- Find and Use Information/Read continuous text/A1.2
- Find and Use Information/Interpret documents/A2.2
- Communicate Ideas and Information/Write continuous text/B2.1
- Communicate Ideas and Information/Complete and create documents/B3.2a
- Understand and Use Numbers/Use measures/C3.3

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

**Materials Required:**

- Pen/pencil and paper and/or digital device
- Scientific calculator or digital device with scientific calculator functions

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

## Learner Information

Plumbers will calculate the linear expansion of pipes when installing to ensure that the correct pipe size is used.

Read "Understanding Linear Pipe Expansion", "Formula for Calculating Linear Pipe Expansion" and "Understanding Exponents".

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

## **Understanding Linear Pipe Expansion**

### **Linear Expansion**

When an object is heated or cooled, its length changes by an amount proportional to the original length and the change in temperature. It is the fractional change in length per degree of temperature change.

### **Thermal Expansion**

When a substance is heated, its particles begin moving more and thus usually maintain a greater average separation. The degree of expansion divided by the change in temperature is called the material's coefficient of thermal expansion and generally varies with temperature.

When water is heated it expands. For example, water heated from 90°F to a thermostat setting of 140°F in a 40-gallon hot water heater will expand by almost one-half gallon. This is because when water is heated, its density decreases and its volume expands. Since water is not compressible, the extra volume created by expansion must go someplace. During no-flow periods in a system, pressure reducing valves, backflow preventers, and other one-way valves are closed, thus eliminating a path for expanded water to flow back to the system supply. Hence, system pressure increases.

### **Coefficient of Thermal Expansion**

The coefficient of thermal expansion describes how the size of an object changes with a change in temperature. Specifically, it measures the fractional change in size per degree change in temperature at a constant pressure. Several types of coefficients have been developed: volumetric, area, and linear.

Heat-induced expansion has to be taken into account in most areas of engineering. A few examples are:

- Metal framed windows need rubber spacers
- Rubber tires
- Metal hot water heating pipes should not be used in long straight lengths
- Large structures such as railways and bridges need expansion joints in the structures to avoid sun kink

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

- One of the reasons for the poor performance of cold car engines is that parts have inefficiently large spacings until the normal operating temperature is achieved.
- A gridiron pendulum uses an arrangement of different metals to maintain a more temperature stable pendulum length.
- A power line on a hot day is droopy, but on a cold day it is tight. This is because the metals expand under heat.
- Expansion joints that absorb the thermal expansion in a piping system.
- Precision engineering nearly always requires the engineer to pay attention to the thermal expansion of his product. For example when using a [scanning electron microscope](#) even small changes in temperature such as 1 degree can cause a sample to change its position relative to the focus point.

Thermometers are another application of thermal expansion — most contain a liquid (usually mercury or alcohol) which is constrained to flow in only one direction (along the tube) due to changes in volume brought about by changes in temperature.

[Source: Adapted from [www.watts.com](http://www.watts.com) and [wikipedia.com](http://wikipedia.com) and [plumbinghelp.ca](http://plumbinghelp.ca)]

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

### **Formula for Calculating Linear Pipe Expansion**

$\Delta T$  - (change in temperature) This is the difference between the initial temperature and the final temperature of the pipe

L -Initial length of the pipe

a - Coefficient of linear expansion for the material

The formula looks like this:  $\Delta L = a L \Delta T$

### **To use the formula, follow the steps below:**

10m length of copper pipe

40° change in temperature

0.000017 is the coefficient of linear expansion of copper

$L = 10$

$a = 0.000017$

$\Delta T = 40$

$\Delta L = 0.000017 \times 10 \times 40$

$\Delta L = 0.0068\text{m}$  - rounded to 7mm

### **Calculating the Coefficient of thermal expansion (a)**

Pipes are made of different material and require different calculations. Below is an example of a calculation for PET (Polyethylene terephthalate) pipe material. The required formula used in the calculation is always pre-determined through the engineering process. Always refer to specifications for each type of pipe used.

Pipe Material = Pre-determined number  $\times 10^{-6}$

PET =  $59.4 \times 10^{-6} = 0.0000594$

The coefficient of thermal expansion (a) is 0.0000594

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

## Understanding Exponents

### Positive Exponent

The positive exponent of a number indicates how many times to use the number in a multiplication.

For example:  $6^3$  - stated as 6 to the power of 3 or 6 to the third power or 6 cubed

Calculating the positive exponent

$$6^3 = 6 \times 6 \times 6 = 216$$

### Negative Exponent

The negative exponent of a number indicates how many times to use the number in a division.

For example:  $6^{-3}$  - stated as 6 to the negative power of 3 or 6 to the minus third power

Calculating the negative exponent

$$6^{-3} = 1 \div 6 \div 6 \div 6 = 4.6296-03$$

$$\text{or } 1 \div (6 \times 6 \times 6) = 1/6^3 = 1/216 = 4.6296-03$$

## Work Sheet

### Task 1: What do the following symbols mean?

Task 1a)  $\Delta T$

Task 1b) L

Task 1c) a

Answer:

---

**Task 2a: Calculate the Coefficient of thermal expansion (a) for the following pipe material and enter it in the chart.**

Material Type	Coefficient of thermal expansion (a)	(a)
ABS	$73.8 \times 10^{-6}$	
Brass	$18.7 \times 10^{-6}$	
CPVC	$66.6 \times 10^{-6}$	
Copper	$16.6 \times 10^{-6}$	
Iron	$12.0 \times 10^{-6}$	
PEX 02 barrier	$140 \times 10^{-6}$	
PEX-AL-PEX	$24 \times 10^{-6}$	
PVC	$110 \times 10^{-6}$	
Steel	$13 \times 10^{-6}$	



Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

**Task 2b) Calculate the linear thermal expansion for the following linear pipe dimensions and temperature change. Use the formula for calculating pipe expansion and the coefficients you entered in the chart.**

- **5m length of ABS pipe with a 35° temperature change**
- **25m length of PEX-02-barrier with a 45° temperature change**
- **50m length of Steel with a 350° temperature change**

Answer:

---

**Task 2c) Calculate the pipe expansion for the following types of pipes. Use this formula  $\Delta L = a L \Delta T$ . Refer to the document Formula for Calculating Linear Pipe Expansion and the answers you entered in the chart.**

- **Iron -  $\Delta T = 110^\circ$ ,  $L = 45\text{m}$ ,  $(a) = ?$**
- **Copper -  $\Delta T = 32^\circ$ ,  $L = 10\text{m}$ ,  $(a) = ?$**
- **Brass -  $\Delta T = 500^\circ$ ,  $L = 9\text{m}$ ,  $(a) = ?$**

Answer:

---

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

**Task 3:** Other than pipes, list three examples of where thermal expansion can occur.

Answer:

---

Task Title:  
CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

## Answers

**Task 1: What do the following symbols mean?**

**Task 1a)  $\Delta T$**

**Task 1b) L**

**Task 1c) a**

Answer:

Task 1a)  $\Delta T$ : Change in temperature. This is the difference between the initial temperature and the final temperature of the pipe

Task 1b) L: Initial length of the pipe

Task 1c) a: Coefficient of linear expansion for the material

**Task 2a: Calculate the Coefficient of thermal expansion (a) for the following pipe material and enter it in the chart.**

Material Type	Coefficient of thermal expansion (a)	(a)
ABS	$73.8 \times 10^{-6}$	0.0000738
Brass	$18.7 \times 10^{-6}$	0.0000187
CPVC	$66.6 \times 10^{-6}$	0.0000666
Copper	$16.6 \times 10^{-6}$	0.0000166
Iron	$12.0 \times 10^{-6}$	0.000012
PEX 02 barrier	$140 \times 10^{-6}$	0.000140
PEX-AL-PEX	$24 \times 10^{-6}$	0.000024
PVC	$110 \times 10^{-6}$	0.000110
Steel	$13 \times 10^{-6}$	0.000013

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

**Task 2b) Calculate the linear thermal expansion for the following linear pipe dimensions and temperature change. Use the formula for calculating pipe expansion and the coefficients you entered in the chart.**

- **5m length of ABS pipe with a 35° temperature change**
- **25m length of PEX-02-barrier with a 45° temperature change**
- **50m length of Steel with a 350° temperature change**

Answer:

5m length of ABS pipe with a 35° temperature change

Thermal expansion = Coefficient (a) x length of pipe x temperature change

Thermal expansion =  $0.0000738 \times 5 \times 35$

Thermal expansion = 0.012915m or 0.013m

The thermal expansion of the ABS pipe will be 0.013m

25m length of PEX-02-barrier with a 45° temperature change

Thermal expansion = Coefficient (a) x length of pipe x temperature change

Thermal expansion =  $0.000140 \times 25 \times 45$

Thermal expansion = 0.1575m or 0.16m

The thermal expansion of the PEX-02-barrier pipe will be 0.16m

50m length of Steel with a 350° temperature change

Thermal expansion = Coefficient (a) x length of pipe x temperature change

Thermal expansion =  $0.000013 \times 50 \times 350$

Thermal expansion = 0.2275m or 0.23m

The thermal expansion of the Steel pipe will be 0.23m

**Task 2c) Calculate the pipe expansion for the following types of pipes. Use this formula  $\Delta L = a L \Delta T$ . Refer to the document Formula for Calculating Linear Pipe Expansion and the answers you entered in the chart.**

- **Iron -  $\Delta T = 110^\circ$ ,  $L = 45\text{m}$ ,  $(a) = ?$**
- **Copper -  $\Delta T = 32^\circ$ ,  $L = 10\text{m}$ ,  $(a) = ?$**

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

- **Brass -  $\Delta T = 500^\circ$ ,  $L = 9\text{m}$ ,  $(a) = ?$**

Answer:

Iron -  $\Delta T = 110^\circ$ ,  $L = 45\text{m}$ ,  $(a) = ?$

$$\Delta L = 0.000012 \times 45 \times 110$$

$$\Delta L = 0.0594$$

Copper -  $\Delta T = 32^\circ$ ,  $L = 10\text{m}$ ,  $(a) = ?$

$$\Delta L = 0.0000166 \times 10 \times 32$$

$$\Delta L = 0.005312$$

Brass -  $\Delta T = 500^\circ$ ,  $L = 9\text{m}$ ,  $(a) = ?$

$$\Delta L = 0.0000187 \times 9 \times 500$$

$$\Delta L = 0.08415$$

**Task 3:** Other than pipes, list three examples of where thermal expansion can occur.

Answer:

- thermometers
- power lines
- railroad tracks

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

### Performance Descriptors

Levels	Performance Descriptors	Needs Work	Completes task with support from practitioner	Completes task independently
A1.2	scans text to locate information			
	locates multiple pieces of information in simple texts			
	makes low-level inferences			
	makes connections between sentences and between paragraphs in a single text			
	follows the main events of descriptive, narrative and informational texts			
A2.2	performs limited searches using one or two search criteria			
	extracts information from tables and forms			
	uses layout to locate information			
	makes connections between parts of documents			
	makes low-level inferences			

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

Levels	Performance Descriptors	Needs Work	Completes task with support from practitioner	Completes task independently
B2.1	writes simple texts to request, remind or inform			
	conveys simple ideas and factual information			
B3.2a	uses layout to determine where to make entries			
	begins to make some inferences to decide what information is needed, where and how to enter the information			
	follows instructions on documents			
C3.3	calculates using numbers expressed as whole numbers, fractions, decimals, percentages and integers			
	manages unfamiliar elements (e.g. context, content) to complete tasks			
	makes estimates involving many factors where precision is required			

Task Title:

CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

Levels	Performance Descriptors	Needs Work	Completes task with support from practitioner	Completes task independently
	chooses and performs required operations; makes inferences to identify required operations			
	selects appropriate steps to solutions from among options			
	identifies a variety of ways to complete tasks			
	interprets, represents and converts measures using whole numbers, decimals, percentages, ratios and fractions			
	organizes and displays numerical information (e.g. graphs, tables)			
	uses strategies to check accuracy (e.g. estimating, using a calculator, repeating a calculation, using the reverse operation)			

This task: Was successfully completed  Needs to be tried again



Task Title:  
CalculatingLinearPipeExpansion\_EAP\_A1.2\_A2.2\_B2.1\_B3.2a\_C3.3

Learner Comments:

Instructor (print):

---

Learner (print):

---